

FIREPRO®

FIRE BARRIER SYSTEM

Preventing the spread of fire and inhibiting the passage of smoke in concealed spaces

ROCKWOOL Fire Barrier is comprised of stone wool and has a galvanised wire mesh which is stitched to one side. Foil faced options and double sided wire mesh are also available. Fire Barrier systems have been developed to prevent the spread of flames and inhibit heat and smoke through concealed spaces in buildings and improve sound reduction. Approved for LUL applications

- Patented 'quick-fit' system for up to 1 hour fire resistance
- Suitable for void heights up to 10.5 meters
- Provides airborne sound reduction
- Additional strength through wire mesh reinforcement
- Service penetration data available
- Fire resistance of up to 2 hours
- Flexible, accommodates movement



FIREPRO® FIRE BARRIER SYSTEM



APPLICATIONS

- Pitched roof voids
- Head of wall
- Concealed ceiling spaces
- Multiple substrates

FIREPRO® FIRE BARRIER SYSTEM

PERFORMANCE

Fire performance

Rating required	Maximum drop without support frame	Maximum drop with additional support frame	Max width	Integrity	Insulation	Install specification	Supporting document
30 min cavity barrier	3m	10.5m	20m	30	15	Single 50mm layer FB, vertical joints butt jointed.	116911
		-		60	15		
30 min fire barrier	6m	N/A	20m	60	30	Single 60mm layer (plain or foil face) with a minimum 100mm overlapped and stitched joints on vertical joints*.	11970
60 min fire barrier	6m	10.5m	20m	60	60	2 layers of 50mm back to back butt jointed with staggered vertical joints between the back to back layers.	116912
90 min fire barrier	3.5m		20m	90	90		51812
120 min fire barrier	3.5m	9m	20m	120	120	2 layers of 60mm (plain or foil face) butt jointed, incorporating a 40mm aircavity between the layers.	44509

N.B. All extensions in drop height must incorporate a minimum 100mm overlap between the sections and stitched with 1.5mm galvanised wire.

*All stitching must be carried out using 0.9mm annealed and galvanised wire. Continuous wire stitching (100mm minimum) or separate lengths of wire secured by twisting ends together. Wire must penetrate through thickness of barrier.

Acoustic performance

The correct use of Fire Barrier within structural cavities and voids will reduce the level of transmitted sound.

Room to room attenuation	R _w dB
Typical lay-in grid suspended ceiling	30
Ceiling and 50mm ROCKWOOL Fire Barrier	42
Ceiling and 50mm ROCKWOOL Fire Barrier Foil Faced	44
Ceiling and 2x layers of 50mm ROCKWOOL Fire Barrier Foil Faced	50

Where plasterboard ceilings are used, add 2-3dB to above performances.

Note: Values quoted are approximate.

FIREPRO® FIRE BARRIER SYSTEM

PRODUCT INFORMATION

Thickness	Length	Width
50mm	4000mm	1000mm
60mm	3500mm	1000mm

One or two sided foil face options available.

Wired mesh is available to both sides if required.

STANDARDS AND APPROVALS

Certificate
Fire Barrier Systems have been independently tested and assessed to BS 476: Part 22 by UKAS accredited laboratories.
ROCKWOOL Fire Barrier system achieves a reaction to fire classification of A1 as defined in BS EN 13501:1
They are third party approved for performance and quality by the Loss Prevention Council Certification board (LPCB) and are listed in their Fire and Security 'Red Book' - certificate no. 022c.
The product has been authorised for use in LUL surface and sub-surface premises when installed in accordance with this data sheet - please refer to the LUL Approved Product Register website www.LU-apr.co.uk for specific details – LUL ref: 2230.



FIREPRO® FIRE BARRIER SYSTEM


INSTALLATION

½ hour cavity barrier

Figures 4-9 show typical details for Fire barrier applied to a timber truss construction as a half hour cavity barrier within the roof section, to satisfy the requirements of building Regulation B3 - (4) i.e. 30 minutes fire integrity and 15 minutes fire insulation.

If the truss is constructed from a minimum timber size of 35 to 49mm thick, both sides of all truss members/bracing require protection from fire in order to minimise charring and retain strength. Figure 6 shows strips of 50mm Fire Barrier used on the reverse side of the truss (for this purpose). Nail plate fixings may fail prematurely in fire unless protected (see Figure 9).

The ROCKWOOL Fire Barrier Fixing System incorporates an angle support and clamping plate (Up to one hour)



ROCKWOOL angle support
ROCKWOOL clamping plate

For fixing to timber, the ROCKWOOL clamping plate is used, compressing the barrier to the timber, fixed at 450mm centres using No. 10 woodscrews.

To use the patented ROCKWOOL angle support system, bend tongues out to 90° and impale barrier onto them. The slotted clamping plate is then fitted by pushing the tongues through the slots, these are then bent over the face of the clamping plate completing the process.


Figure 4
Fire Barrier traverse to rafters



Allow sufficient material to pack and stitch Fire Barrier between rafters as shown
Tongues at max 450mm centres
Continuous angle support secured to underside of each rafter with no 10 wood screws
RW clamping plate

Figure 5
Half hour protection for timber truss construction 50mm thick or more.

Note: nail plate protection required - see Figure 6



RWA45
Tiled or slated roof
No. 10 wood screws at maximum 450mm centres
RW clamping plate
ROCKWOOL 50mm Fire Barrier tightly butt joined and stitched (see Fig. 15)
Minimum 50mm thick timber trussed rafter
No. 10 wood screws at maximum 450mm centres
Clamping plate


FIREPRO® FIRE BARRIER SYSTEM

Figure 6
Half hour protection for timber truss construction 35 to 49mm thick.




- RWA45
- Tiled or slated roof
- 35-49mm thick timber trussed rafter
- 0.9mm wire stitching to secure strips to main barrier stitches typically 100mm long
- No. 10 wood screws (or large washer and screws) at maximum 450mm centres
- 50mm Fire Barrier

Figure 7
Head of partition



- ROCKWOOL Fire Barrier
- RW clamping plate
- No.10 wood screws at max 450mm centres
- Head plate
- Ceiling board

Figure 8
Barrier fitted transversely to timber joisted ceiling



- Tongues fixed at max 300mm centres
- Angle support fixed to ceiling joists

Figure 9
Nail plate protection



- 25mm thick ROCKWOOL BeamClad® fixed with Firepro Glue and nailed, or 50mm Fire Barrier secured with screws and large square washers. Use 50mm nails for BeamClad® and 70mm screws for Fire Barrier.

FIREPRO® FIRE BARRIER SYSTEM

For fixing to concrete soffits (Figure 10-12), the pre-punched angle support is fixed using Hilti DBZ or Ejot ECL 35 hammer set anchors at max. 750mm centres. For fixing to steel purlins, use Hilti SMD 02Z (5.5 x 70mm) self-tapping screws at maximum 450mm centre.

Figure 10
50mm Fire Barrier fixed to concrete soffit.



Support angle fixed to soffit at max 750mm centres

Figure 11
50mm Fire Barrier running across ribbed soffit - Section



RW clamping plate fixed at 450mm centres

Angle support fixed as Fig10

Barrier cut and packed into troughs and wired to prevent uncoiling

Figure 12
Alternative fixing to flat soffit or perimeter, appropriate to barriers with a shallow drop



50mm Fire Barrier compressed between soffit and clamping plate at max 450mm centres

Hilti DBZ 6/4.5 or Ejot ECL 35 hammer set anchor

FIREPRO® FIRE BARRIER SYSTEM

60-30 Fire Barrier

If 30 minutes insulation is required, use 1 layer of 60mm plain or foil-faced fire barrier with 100mm vertical over lapped joints (Figure 13 & 14). The barrier is otherwise fixed for timber construction as previously shown on Figures 4-9.

Figure 13




Figure 14



FIREPRO® FIRE BARRIER SYSTEM

Common details

Extended drops

ROCKWOOL 50mm Fire barrier single and double layers, can be extended from a 3.5m drop to a maximum 6m drop by fixing an additional 2.5m section, stitched with overlapped joints as per Figure 16. For additional guidance and drops in excess of 6m, please refer to Figure 31 and associated guidance.

Wire stitching of butt joints in ROCKWOOL Fire Barriers

Adjacent barriers must be closely butt jointed, or overlapped, and through stitched with 0.9mm galvanised annealed wire (see Figure 15). It is essential that the barrier provides a good seal at its head, perimeter and at all joints. Where the barrier abuts a profile such as a trapezoidal deck, the material must be cut to suit and secured to fire stop the gap (see Figure 17). For extended drops, 1.5mm diameter galvanised and annealed wire is used (see Figure 16).

Figure 15





Figure 16



Figure 17



- Fire Barrier cut and pushed up into profile as fire stopping
- Angle or clamping plate fixing Fire Barrier to purlin with self tapping screws at 450mm centres (Hilti SMD 02Z 5.5 x 70mm)
- Adjacent Barriers butt jointed and wired tightly together as Fig15
- Fire Barrier draped over suspended ceiling and wired to grid, min 100mm lap. If not wired, overlap is min 150mm

FIREPRO® FIRE BARRIER SYSTEM

Penetration details

It is regarded as good practice to adequately support or reinforce services penetrating compartment walls and cavity barriers, to prevent displacement. It is recommended that such supports should be no greater than 500mm from each face of the Fire Barrier.

To maintain the integrity of the Fire/Cavity Barrier when penetrated by services with a high melting point (such as steel or copper pipes, beams or trusses) the barrier is first cut locally to accommodate the service or structural member and then re-stitched as neatly as possible. The penetration is then lightly sleeved each side of the barrier to a minimum length of 300mm, using the same barrier material. Each sleeve should be securely stitched to the main barrier to produce a tight seal and prevent future detachment (see Figures 18 and 19). Where access is only available from one side, the double seal solution may be replaced by a single 'collar' detail - please contact our Technical Solutions Team for further advice.

If the penetrating service is manufactured from low melting point materials such as plastic or aluminium, then sleeving should be extended to at least 1000mm either side of the barrier.

This guidance applies to services such as pipes, sheathed cables and conduits, including those carried on steel trays.


For protected steel ductwork with a tested fire resistance performance (stability, integrity and insulation) at least the same as the Fire Barrier, 300mm sleeves should be applied either side of the main barrier, as for high melting point services above.

For information on achieving fire protection to steel ductwork, please refer to the ROCKWOOL Fire Duct System data sheet.

For non-fire protected ductwork, or that with a fire resistance performance less than the barrier, two sleeves should be applied to each side of the barrier, an inner sleeve of 1000mm and an outer sleeve of 300mm. All sleeves should be stitched to the main barrier.

The duct should also include an independently supported fire damper, located in the line of the main barrier. Reference should also be made to Approved Document B of England & Wales Building Regulations - Volume 1, Requirement B3, Section 7 and Volume 2, Requirements B3, Section 10.

Figure 18



FIREPRO® FIRE BARRIER SYSTEM

Figure 19



Sleeves to be stitched to main barrier
Off-cuts of Fire Barrier to be packed tightly into purlin void

1 hour Fire Barrier

The unique, patented ROCKWOOL support angle and clamping plate is used to fasten two 50mm Fire Barrier curtains with one support angle without the need for a cavity.

The ROCKWOOL support angle has tongues that are pushed out from opposite sides at 300mm max. centres. The ROCKWOOL Fire Barriers are then impaled on the tongues on both sides and clamped using the ROCKWOOL clamping plates. The tongues are finally bent over the clamping plates, completing the system.

The system uses 50mm Fire Barrier in a double layer with joints staggered. (Please note; wire reinforced sides should be placed outwards).

Figure 20



Concrete soffit
Fire Barrier support angle
Hilti DBZ 6/4.5 or Ejoyt ECL 35 hammer set anchor at max 750mm centres
Two layers of 50mm Fire Barrier with joints staggered


Figure 21



Clamping plate
Screw system at max 450mm centres


FIREPRO® FIRE BARRIER SYSTEM

Figure 22



- Clamping plate
- Hilti hammer screws at max. 450mm centres

Figure 23




- Concrete soffit
- Support angle fixed to soffit at max 750mm centres
- Clamping plate fixed at 300mm centres
- Two layers of 50mm Rockwool Fire Barrier, vertical joints staggered and stitched and clamped to head of wall
- Suspended ceiling
- Fire-resisting wall

Fixing to timber structure (1 hour)

When a 1 hour Fire Barrier is supported on structural timber (for example a trussed rafter), and the thickness of timber is 35-49mm, one layer of 60mm ROCKWOOL Fire Barrier must be placed on each side of the timber (see Figure 24). Where timber thickness is 50mm or greater, 2 layers of 50mm Fire Barrier are sufficient.

Figure 24



- Fill space between battens with 300mm wide RWA45
- RW clamping plate
- No.10 wood screws at maximum 450mm centres
- 35mm thick timber trussed rafter
- 60mm ROCKWOOL Fire Barrier tightly butt joined and stitched (see Fig.15)
- 1 hour fire rated ceiling
- Clamping plate
- No.10 wood screws at maximum 450mm centres


FIREPRO® FIRE BARRIER SYSTEM

1.5 & 2 hour Fire Barriers

1.5 hour Fire Barrier

The ROCKWOOL 1.5 hour Fire Barrier system uses 2 layers of 50mm Fire Barrier with staggered joints fixed as Figures 25-27. Please note: Wire reinforced faces should be placed outwards.

Figure 25




- Concrete soffit
- 2mm tested angle fixed to soffit at max 750mm centres (see Fig. 26).
- Clamped at max 300mm centres with M6 bolts and nuts
- Two layers of 50mm ROCKWOOL Fire Barrier, vertical joints staggered and stitched
- Suspended ceiling
- Fire-resisting wall

Figure 26



- Concrete soffit
- 2mm tested angle fixed to soffit at max 750mm centres
- M8 expanding bolt anchors at max. 750mm centres
- M6 bolts and nuts staggered each side
- 2mm tested punched strap
- Two layers of 50mm Fire Barrier with vertical joints staggered

Figure 27



- 2mm tested punched strap
- Hilti HUS universal Screw System max. 300mm centres

FIREPRO® FIRE BARRIER SYSTEM

2 hour Fire Barrier

The ROCKWOOL 2-hour Fire Barrier (see Figures 28-30) consists of two layers of 60mm (plain or foil-faced), wire stitched Fire Barrier with staggered vertical joints, separated by a nominal 40mm air space. The base or perimeter to which the barrier is fixed must be capable of remaining in place for 2 hours.

Figure 28



Figure 29



Figure 30



Angle and strap for 1.5% and 2 hour Fire Barriers

The following specification for slotted angles and straps is suitable for supporting ROCKWOOL Fire Barriers for 1.5 and 2 hours when tested to BS 476: Part 22. Slotted angles (62 x 41 x 2mm) and straps (38 x 2mm) manufactured from mild steel conforming to BS 1449: Part 1.1: 1991 and cold reduced to provide a minimum of 0.2% proof stress of 417 Mpa (27 tons/ in²) and conforming to BS 4345: 1968 (1986) - Specification for slotted angles (inc. flat strap).

FIREPRO® FIRE BARRIER SYSTEM

OTHER INSTALLATION INFORMATION

General design considerations

A cavity fire barrier must be designed to restrict the passage of both hot smoke and flames for the minimum specified period, as listed in Approved Document B in support of the Building Regulations. In addition, it must be fixed in such a way that:

- It will remain effective in the event of structural movement
- There are no gaps where it abuts other elements of construction
- It complies with the requirements of Approved Document B of the Building Regulations

Extended drops

For periods of up to 60 minutes, ROCKWOOL Fire Barriers can be used for extended void heights between 3.5 and 6m without the need for a supported frame - see Figure 16 for joining barriers with overlap. For periods of up to 90 minutes, this drop height can be increased to 10.5m (9m for 120 minutes), by the use of a simple frame system constructed from slotted angles and straps (see Figure 31).

Further details are available from ROCKWOOL Technical Solutions Team.


Fire barriers and dampers

Where ROCKWOOL Fire Barriers are installed in conjunction with fire dampers, the dampers must be supported independently of the fire barrier. HVCA or ASFP publications may be helpful.

Access through barriers

Where regular access is required through the barriers for maintenance purposes etc, this should be achieved by the inclusion of an independently supported fire rated door set and frame. The Fire Barriers should be clamped to the door frame with the RW clamping plate and appropriate fixings at 450mm centres.

Figure 31



FIREPRO® FIRE BARRIER SYSTEM

ROCKWOOL ancillaries

ROCKWOOL Fire Barrier support angle and clamping plate are specially manufactured for ROCKWOOL.

Clamping Plate:

3m x 40mm, 10 lengths per pack

Fire Barrier Support Angles:

3m x 34mm x 75mm, 10 lengths per pack

Proprietary fixings

All steel hammer set expansion anchors for soffit fixings are available from Hilti, or Ejot. For perimeter fixings to concrete or masonry, use Hilti HUS Universal Screw system. For fixings to timber, use standard No. 10 steel wood screws 100mm long.

Durability

For durability, we recommend that the finish should be capable of withstanding at least 200 hours salt spray and 400 hours humidity corrosion resistance testing to BS 3990: Part F. Slotted angles and straps conforming to this specification are available from the following suppliers: JB Products Tel: 01384 240234 Link 51 Tel: 01952 682251 Romstor Tel: 01442 242261

If other hardware is used to support the barriers, we recommend that the respective specifier, supplier or installer should be certain that the chosen fixing system has been both tested and approved, for the required period of fire resistance and drop height.

Packaging of Fire Barrier

Shrink wrapped in polyethylene

Handling

ROCKWOOL Fire Barriers are easy to handle. It is easy to cut to any shape. The product should be stored indoors or under a weatherproof covering.

Maintenance

Once installed ROCKWOOL Fire Barriers should need no maintenance. Fire Barriers should be inspected to ensure that they have not been disturbed during maintenance of areas and/or as part of a regular maintenance program.

FIREPRO® FIRE BARRIER SYSTEM

SPECIFICATION CLAUSES

ROCKWOOL Fire Barrier System is associated with the following NBS clauses:

K10: Gypsum board dry linings/partitions/ceilings

530 – Cavity fire barriers within partitions/wall linings

545 – Cavity fire barriers within suspended ceilings

KK40: Demountable suspended ceilings

287 – cavity barriers

425 – Installing cavity barriers

431 – Installing sound barriers

P10: Sundry insulation/proofing work

410 – Flexible cavity barriers

430 – Wired mineral wool small cavity barriers

440 – Fire protection

FIREPRO® FIRE BARRIER SYSTEM

DISCLAIMERS

ROCKWOOL Limited, its affiliates, its agents and employees and all persons acting on its or their behalf (collectively "ROCKWOOL"), disclaim any and all liability for any errors, inaccuracies or incompleteness contained in any datasheet or in any other disclosure relating to any product. Usage of the information remains under the sole responsibility of the purchaser and/or user.

ROCKWOOL makes no warranty, representation or guarantee regarding the information contained in the data sheet, the suitability of the products for any particular purposes or the continuing production of any product. To the maximum extent permitted by applicable law, ROCKWOOL disclaims (i) any and all liability arising out of the application, use of any product, misuse or inability to use the product (ii) any and all liability, including without limitation special, consequential or incidental damages, and (iii) any and all implied warranties, including warranties of fitness for particular purpose, non-infringement and merchantability.

Information contained in this data sheet is up-to-date as at the date of issue. As ROCKWOOL Limited cannot control or anticipate the conditions under which this product may be used, each user should review the information in specific context of the planned use. To the maximum extent permitted by law, ROCKWOOL Limited will not be responsible for damages of any nature resulting from the use or reliance upon the information contained in this data sheet. No express or implied warranties are given other than those implied by law.

SUPPORTING INFORMATION

For further information relating to any aspect of the FIREPRO range, please refer to the applicable ROCKWOOL standard details at www.rockwool.com/uk or contact the ROCKWOOL technical solution team on 01656 868490 or technical.solutions@rockwool.com.

SUSTAINABILITY

As an environmentally conscious company, ROCKWOOL promotes the sustainable production and use of insulation and is committed to a continuous process of environmental improvement.

All ROCKWOOL products provide outstanding thermal protection as well as four added benefits:



HEALTH & SAFETY

The safety of ROCKWOOL stone wool is confirmed by current UK and Republic of Ireland health & safety regulations and EU directive 97/69/EC:ROCKWOOL fibres are not classified as a possible human carcinogen.

A Material Safety Data Sheet is available and can be downloaded from www.rockwool.com/uk to assist in the preparation of risk assessments, as required by the Control of Substances Hazardous to Health Regulations (COSHH).

ENVIRONMENT

Made from a renewable and plentiful naturally occurring resource, ROCKWOOL insulation saves fuel costs and energy in use and relies on trapped air for its thermal properties.

ROCKWOOL insulation does not contain (and has never contained) gases that have ozone depletion potential (ODP) or global warming potential (GWP).

ROCKWOOL is approximately 97% recyclable. For waste ROCKWOOL material that may be generated during installation or at end of life, we are happy to discuss the individual requirements of contractors and users considering returning these materials to our factory for recycling.